



KitchenAid Classic Mixer K45SSWH Beater Head Adjustment

If the beater head for your mixer touches the bowl or is too high, this guide will help you adjust its height to an optimal level.

Written By: Markus Gemperle



INTRODUCTION


Adjusting the beater head is a simple process involving only some handling of a screwdriver.



TOOLS:

- [Flathead Screwdriver](#) (1)
-

Step 1 — Adjust the height



- Lift the mixer arm and locate the large screw where the base meets the arm.
- Using a flathead screwdriver, turn the screw counter-clockwise to raise the beater head or turn it clockwise to lower the beater head.
- ⓘ The beater head should pass only about 1/16th of an inch above the base of the bowl. One good way to get the height right is to place a dime in the bowl and adjust the height until the beater head barely brushes the dime as it passes.

Once your beater head is at the appropriate height, you're good to go.

This document was last generated on 2017-07-01 06:36:17 AM.